

Proceq Europe

Ringstrasse 2
CH-8603 Schwerzenbach
Phone +41-43-355 38 00
Fax +41-43-355 38 12
info-europe@proceq.com

Proceq USA, Inc.

117 Corporation Drive
Aliquippa, PA 15001
Phone +1-724-512-0330
Fax +1-724-512-0331
info-usa@proceq.com

Proceq Asia Pte Ltd

12 New Industrial Road
#02-02A Morningstar Centre
Singapore 536202
Phone +65-6382-3966
Fax +65-6382-3307
info-asia@proceq.com

Proceq Rus LLC

Ul. Optikov 4
korp.2, lit. A, Office 321
197374 St. Petersburg
Russia
Phone/Fax + 7 812 448 35 00
info-russia@proceq.com

Proceq Middle East

P.O. Box: 262419
Jebel Ali Free Zone
Dubai, United Arab Emirates
Phone +971 50 482 9510
info-middleeast@proceq.com

Proceq SAO Ltd.

South American Operations
Rua Haddock Lobo, 746 - 5 andar
Cerqueira Cesar, São Paulo
Brasil Cep. 01414-000
Phone +55 11 3083 38 89
info-southamerica@proceq.com

Proceq Asia Pte Ltd Shanghai Rep Office

Unit G, 10th Floor, Huamin •Empire Plaza
No. 728, Yan An Road(W)
Shanghai, 200050
Phone +86 21-63177479
Fax +86 21 63175015
info-china@proceq.com

www.proceq.com


Additional Memory Function **Rebar Detector and Covermeter**



proceq

proceq


Additional Memory Function of the Profoscope*



Select memory card symbol to activate the data storage mode.

Minimum cover function is automatically deactivated if the memory function is turned on.


Two different memory functions are supported:



Manual: After locating, cover value and rebar diameter can be stored by the operator.

Auto: Used for surface scans. Every time a rebar is detected, the cover value is stored automatically.

After selecting the memory function, the status line on the measuring screen is modified:




- Manual Storage Mode
- Automatic Storage Mode
- Memory card missing or defective

Object number (max.500)
Measurement number (max.99)


It is recommended to set up a separate object for each structural element (e.g. column, wall). Every measuring position on this object can then be assigned to a measurement number.

Manual Storage Mode:



- Estimate diameter and store values
- Delete last measurement
- Open next object

Automatic Storage Mode:



- Start / Stop automatic storage (blinking while recording)
- Delete last object
- Open next object


Rebar diameter is not stored in the automatic mode.

Quick Reference Guide to the Profolink

Installation


Locate the file „Profolink_Setup“ on your computer or the CD and follow the installation wizard.

Open the battery compartment and connect the Profoscope* to the USB port. If the icon appears on the Profoscope* screen, the connection is established properly.




1. Download objects from the Profoscope*
2. Expand object to see details
3. Measurement number
4. Cover value

5. Rebar diameter
6. Add object name
7. Switch between regional settings or units
8. Add comments




Select the menu “delete all objects” to delete all data stored on Profoscope*. This will delete all objects and cannot be undone.



“Add” function synchronizes data between PC and Profoscope*. In addition, locally stored data files can be added to an existing project.

Data Management and File structure:

Profoscope*



PC / Profolink

