SENKO



SP Secure Portable Gas Leak Detector

SP secure is a portable gas leak detector designed for operators to detect the presence of **LPG/LNG** including **methane & combustible gases,** near any gas pipes and valves.

The instrument features **a built in sampling pump** for on - site gas leak detection. Take near any pipe/valve & the instrument will provide a value on the LCD display of the gas concentration & an alarm in case of gas leakage

Instrument is also available for **H₂& Xylene** gas leak detection options.

Model	SP Secure				
Detecting Gas	LNG, LPG	Hydrogen(H₂)		Xylene	
Sampling Method	Internal Sampling Pump, flow rate 0.5 liter/min.				
Sensor Type	Catalytic	Catalytic	Electrochemical	IR	
Detecting Range	0~100%LEL	0~100%LEL	0~1000ppm	0~100%LEL	
Response Time(T ₉₀)	<10 sec/90% scale	<10 sec/90% scale	<75 sec/90% scale	<30 sec/90% scale	
Resolution	1%LEL	1%LEL	Within 5 ppm	1 %LEL	
Accuracy	+/- 3% full scale				
Display	Digital LCD with backlight (Alarm, Buzzer, Pump On-Off, Battery)				
Alarm	Buzzer alarm & LCD Display, Alarm set programmable				
Gas Concentration Display	1~100% LEL- numerical display, 0~1% LEL-digital bar	0~1,000 ppm - numerical display, 0~20 ppm - digital bar		1~100% LEL- numerical display, 0~1% LEL-digital bar	
Explosion Proof	Ex d ia IIB T3				
Operating Temperature	- 20°C ~ +50°C				
Power	Rechargeable AA Alkaline battery 3nos, included with charger				
Continuous Operation	More than 12 hours				
Size / Weight	WHD 55mm x 241mm x 33 mm / 260g				
Standard Accessories	Protect Cover, Adapter for charge				
Part No.	SSC000110	SSC <mark>00</mark>	00210	SSC000310	



Applications:

- Methane Gas leak detection near pipes
- LPG Gas Leak detection
- Propane Gas Leak detection
- LNG Gas Leak detection
- Xylene industrial Gas Leak Detection

Alarm Feature



Audio

Alarm Modes:

Alarm	Standard for Alarm	LCD Display	Alarm Sound
1 st Alarm	When exceeding the value set for 1 st Alarm	Warning! and indicates LO	
2 nd Alarm	When exceeding the value set for 2 nd Alarm	Warning! and indicates HI	
Low	One level only left unused	Blinking Battery	П
Dead	Exhausted	Blinking Battery	
Test Failure	Failure of sensor test Failure of calibration	Displays Icon	П